



**User Manual
“GT-20 v1.6 configurator”**



List of Tables

ABOUT THE PROGRAM	3
1. INSTALLATION AND PROGRAM STARTUP	4
2. BUTTONS OF A TOP PANEL	7
3. STATUS BAR	10
4. VERTICAL MENU	11
4.1. MONITORING	11
4.2. SETTING OF CONNECTION	13
4.3. NAVIGATION PARAMETERS	18
4.4. INPUTS	23
4.5. OUTPUTS	26
4.6. SECURITY	28
4.7. POWER	30
4.8 PERIPHERY SETUP	32
4.9 AUTO INFORMER	38
4.10 EVENT PROCESSING	41
4.11. VOICE MESSAGE	44
4.12. DIAGNOSTICS FILE	46

About the program

«GT-20 configurator» allows executing the following operations:

- Device monitoring in real-time with status display of its main components;
- Device configuring via the graphic interface;
- Device diagnostics with the saving of information in the log-file;
- Update the firmware device.

1. Installation and program startup

Run of a CD, or download from a site the program Setup_Configurator.exe and follow instructions. In case of security warning of your computer confirm installation and program startup.

Run the program GT-20 Configurator (from Start menu \Programs \NAVISET). Turn on the power supply of a device and connect it via USB cable to your computer. Having found the new device, the operating system will suggest installing the driver.




Figure 1.1




Figure 1.2

Do not modify the default settings, i.e. leaving "automatic installation", click "Next".




Figure 1.3

Click the button "Ready" after the operating system installing the appropriate device drivers, for a completion of master operation.




Figure 1.4

Further pass to the menu «Setup \Connection ...» and in the dropdown list select Com port to which the device is connected, and click "OK".

Connection




Figure 1.5

If the device is defined by a configurator, all buttons of a top panel will be active, and in status bar there will be a message «Connected». If the device wasn't found, pass to the above described menu and select other Com port.

The type of "TCP/IP" connection is used for remote device configuring.

If you select this type of connection, you see the "Server" window (Figure 1.6). In this window, enter the available port of the system and press the "Start", after that the server will wait to connect with a device. Further send to the device SMS COM5 command (see the passport) with IP address and server port. After connection setting, menu buttons will become active.





Figure 1.6

Visual appearance of the «GT-20 v1.3 Configurator» is shown in Figure 1.7.



1. GT-20 Configurator
 2. Monitoring
 3. Connection setting
 4. Navigation setting
 5. Inputs
 6. Outputs
 7. Security
 8. Power supply
 9. Peripheral configuration
 10. Auto informer
 11. Event process
 12. Voice message
 13. Diagnostic file
 14. Identification data
 15. Device ID
 16. IMEI

17. Firmware
 18. Navigation information'
 19. Date and time
 20. Latitude
 21. Longitude
 22. Height
 23. Speed, km/h
 24. Heading, degree
 25. Visible satellites
 26. Horizontal delicacy
 27. Coordinates
 28. Jump
 29. Acceleration
 30. Turning angle
 31. Distance traveled, m
 32. Period of packet

33. The last written packet
 34. The last transferred packet
 35. Analog inputs/outputs/state of device
 36. 1-8 inputs
 37. 1-4 outputs
 38. Temperature of device
 39. Level of GSM signal
 40. U power
 41. U battery
 42. State
 43. External periphery
 44. 1-8 temperature

44. Fuel level sensor
 45. 1 level
 46. 1 temperature
 47. 2 level
 48. 2 temperature
 49. Fuel level, %
 50. Tachometer, r/sec
 51. Coolant temperature, degree
 52. Motometer, h
 53. Total distance, km
 54. Total fuel consumption, l
 55. Total mass of vehicle, kg
 56. Axle

Figure 1.7

2. Buttons of a top panel




Figure 2.1

The **"File"** menu contains the basic operations of configuration file:

- Run configuration by default;
- Open the configuration file;
- Save a configuration.

Points of this menu are duplicated on a panel below by buttons 1,2,3 respectively (a figure 2.1).

"Settings" menu. Menu selects the type of connection ("Connecting ..."), (Figure 2.2), and turning on / off mode of diagnostics in real time (Figure 2.3).



Figure 2.2




Figure 2.3

The following buttons are active in case of connection is set with a device.

Button **"Read"** (4) allows reading the current configuration of the device. Read data are displayed in the appropriate fields of the program. Course reading is displayed in the window (Figure 2.4).




Figure 2.4

After configuration reading it will be reported of one of this message:

- **"Configuration is read"** all data has been read;
- **"Not all data is read, update a configurator"**. This message will appear if device software version is newer, i.e. added new parameters which the configurator can't display.
- **"Try again"**. This message will appear, if for whatever reason it was not possible to read a configuration. Check connection with the device.

"Write" button (5) allows writing a configuration on the device (Figure 2.5).




Figure 2.5

After the configuration writing it will be reported of one of this message:

- **"The device configuration is updated"**. The operation of configuration writing is successfully executed.
- **"The configuration isn't written, it is necessary to update a configurator"**. The reason of this message is insufficiency of data for configuring, i.e. the version of a device software is newer with new parameters.
- **"Failed to update the configuration"**. It was not possible to write a configuration for any reason.

Button "**Delete Track**" (6). Used in the event if the structure of the package store was changed in the internal memory (specified in the manual's part of firmware description) or just to remove the accumulated packets. After clicking this button, it is appeared a window "**Confirm**"(Figure 2.6), which requires a password to complete the operation ("1234").




Figure 2.6

Button "**Update SW**" (7). It allows using this configurator to update device software (figure 2.7).

To update device software click the button «...» and select "**firmware_XXX.bin**" file where XXX indicates the software version.

If the selected file corresponds to required parameters, the button "**Update program**" will be active, otherwise the message "**The opened file is not a firmware file!!!**" will appear.

To start the update, click the button "**Update the program**". The device will reboot and start programming. After programming completion the device will reboot and will return again to an operating mode.




Figure 2.7

"Reboot" button (8). It is used for device reset without switching off to apply the made changes in a configuration.

3. Status bar



Figure 3.1

The status bar is separated into four windows (figure 3.1).

The window "1" displays information of the open, read or saved configuration file and can have following values:

- **"default.fcg"**. The configuration data is loaded by default.
- **"C:\My_conf.fcg"**. The configuration is loaded from the My_conf.fcg file from the root directory of the disk C:\ or if you are saving a file, the name of the saved file is displayed.
- **"Read from a device"**. Configuration was read from the device.
- **"Impossible to open"**. No access to open the file.
- **"Unable to save"**. The disc writing might be forbidden.
- **"File is not found, default.fcg is loaded"**. During startup, the configurator tries to open the last open or save file if the file is not found or access to it is forbidden, the configuration is loaded by default.

The window "2" displays number of the current Com-port through which is using now. Inscription "NC" indicates that the selected Com-port does not exist or cannot be opened. Go to the menu "Settings \ Connection ..." and select the appropriate port.


The window "3" indicates device state: the device does not move and has a state of "parking" or is moving and has a state of "movement." It can be used to configure the sensitivity of motion sensor.

The window "4" displays connection mode information:

- **"Connected"**. Connection with the device was set. Reception of information.
- **"V.1.0 loader mode"**. Connection was set with the device loader, the loader version information is provided here.
- **"The device isn't found"**. It is displayed if the device doesn't respond to configurator commands.
- **"Port Com setup ..."**. It is displayed when we are in the menu «Com port ...».

4. Vertical menu

4.1. Monitoring




1. GT-20 Configurator	17. Firmware	33. The last written packet	46. 1 level
2. Monitoring	18. Navigation information'	34. The last transferred packet	47. 1 temperature
3. Connection setting	19. Date and time	35. Analog inputs/outputs/state of device	48. 2 level
4. Navigation setting	20. Latitude	36. 1-8 inputs	49. 2 temperature
5. Inputs	21. Longitude	37. 1-4 outputs	50. Fuel level, %
6. Outputs	22. Height	38. Device temperature	51. Tachometer, r/sec
7. Security	23. Speed, km/h	39. Level of GSM signal	52. Coolant temperature, degree
8. Power supply	24. Heading, degree	40. U power	53. Motometer, h
9. Peripheral configuration	25. Visible satellites	41. U battery	54. Total distance, km
10. Auto informer	26. Horizontal delicacy	42. State	55. Total fuel consumption, l
11. Event process	27. Coordinates	43. External periphery	56. Total mass of vehicle, kg
12. Voice message	28. Jump	44. 1-8 temperature	57. Axle
13. Diagnostic file	29. Acceleration	45. Fuel level sensor	58. Copy
14. Identification data	30. Turning angle		
15. Device ID	31. Distance traveled, m		
16. IMEI	32. Period of packet		

Figure 4.1

This window displays information of the device and a status of its main nodes:

- Identification data, such as number of the device, IMEI and software version;
- Navigation data (coordinates, height, speed, heading, quantity of satellites, etc.);
- The voltage of the analog inputs, external voltage, the internal battery;
- A state of outputs (0 – passive, 1 – active);
- Data of motion sensor axes;
- Internal temperature of the device;
- Level of GSM signal;
- GSM / GPRS registration State (0 - unregistered, 1 - registered, home network, 2 - unregistered, the search of operator, 3 - registration is cancelled, 4 - unknown, 5 - registered, roaming);
- Information of the external periphery (indication of temperature sensors, fuel level, the key code of iButton, distance travelled, etc.).

4.2. Setting of connection



1. GT-20 Configurator
 2. Monitoring
 3. Connection setting
 4. 1 connection
 5. 2 connection
 6. 3 connection
 7. 4 connection
 8. 5 connection
 9. Navigation setting
 10. Inputs
 11. Outputs
 12. Security
 13. Power supply
 14. Peripheral configuration
 15. Auto informer
 16. Event process
 17. Voice message

18. Diagnostic file
 19. Device ID
 20. Voice connection parameters
 21. Microphone gain
 22. Dynamics gain
 23. Number of tone after auto answering
 24. Voice menu volume, auto informer
 25. GPRS connection parameters
 26. IP server address
 27. Server port
 28. 1 SIM card (operator)
 29. Beeline
 30. Other

31. Megaphone
 32. MTS
 33. Tele 2
 34. # Server
 35. Login
 36. Password
 37. 2 SIM card (operator)
 38. Beeline
 39. Other
 40. Megaphone
 41. MTS
 42. Tele 2
 43. # Server
 44. Login
 45. Password
 46. Auto update
 47. Server address IP

48. Number of month
 49. Server port
 50. Radio silence mode
 51. Time of log-on
 52. Sleep mode after transmission
 53. Access password
 54. Involve DTMF
 55. Receive SMS of any number
 56. Confirmation of SMS command
 57. SMS in case of balance lower
 58. Forbid auto switching of SIM cards

Figure 4.2

The setting of common connection parameters is completed in this window:

- Device ID. Device peculiar number, assigned by a system;
- Voice connection parameters;
- GPRS connection parameters, where identified IP address and server port on which will send data of device. Also you will need to specify which operator you used SIM cards, if there is not your operator in list, select point "Other" and identify parameters on your own;
- Auto update: IP address and server port with which the device will connect downloading update in assigned date "Date" of each date;

"Radio silence mode". Switching on present parameter is activated the Radio silence function: the device connects at set intervals. Radio communications is active during fixing period of time (10min), after that the device will in radio silence mode.

"Time of log-on" specifies time interval of log-on with a server.

"Sleep mode after transmission". In case of active parameter the device will select immediately radio silence mode after transmission of all stored data packets without waiting for specified time interval.

"Access password". It is a password allowing access to configuration via SMS or control via DTMF;

"Confirmation of SMS command". Confirmation of completed command will sent per each correct accepted SMS command.


"SMS in case of balance lower". Control a SIM card balance. When the balance is lower identified level the SMS will sent to the first number of the list.

"Involve DTMF". This parameter allows operation of DTMF decoder. With this enabled parameter it is possible to work with voice menu and operate device.

"Receive SMS of any number". Allows accept SMS of any telephone number.

"Forbid auto switching of SIM cards". When the device has not GSM connection, it does not switch to another SIM card, and continue operating of current SIM card until connection reactivation. Switching to another SIM card is possible to do via command.

The setting of each 5 available connection parameters is completed in this window. Message is sent if some of required source has an active move, separately to dial-up and SMS.



- 1. GT-20 Configurator
- 2. Monitoring
- 3. Connection setting
- 4. Connection 1-5
- 5. Navigation setting
- 6. Inputs
- 7. Outputs
- 8. Security
- 9. Power supply
- 10. Peripheral configuration
- 11. Auto informantor
- 12. Event process
- 13. Voice message
- 14. Diagnostic file

- 15. Connection 1
- 16. Number
- 17. Message type
- 18. Received call
- 19. Received message
- 20. Dial-up
- 21. Quantity
- 22. Connection duration
- 23. Suffice to dial-in for message delivery
- 24. Source
- 25. Input 1-8
- 26. Security
- 27. Monitoring

- 28. No external power
- 29. Accelerometer
- 30. SMS
- 31. Source
- 32. Input 1-8
- 33. Security
- 34. Monitoring
- 35. No external power
- 36. Accelerometer
- 37. Dial-up
- 38. Accept
- 39. Ignore

Figure 4.3

In the field "**Number**" enter a telephone number, to which will called or sent SMS. To number "Connection 1" make a call pressing a button "Call manager" or send a service SMS, because of that it is desirable to indicate number of your control center.

In the field "**Message type**" available to select one of the 4 variants:

- "**Dial-up**". Dial-up to specified number and if the parameter "Involve DTMF" is enabled and SD card is installed with a files per each "source", the respective message will be displayed;
- "**Dial-up and SMS**". Above described is doubled sending respective SMS;
- "**SMS**". Send only SMS.
- "**SMS, if failing dial-up**". SMS is sending when the dial-up is failing.

In the field "**Received call**" available to select one of 4 variants:

- "**Accept**". After the specified number of tone in the menu "Connection setting" the device will be automatic answered to a call. Answering to a call the audio interface is switched and via it is available to listening;
- "**Accept and go to voice menu**". Additionally to above described, the voice menu is switched on, on conditions that parameter "Involve DTMF" is active, via which you control outputs of device or request current device state;
- "**Change the security mode**". Identifying the number of caller the device select security mode to the opposite one, i.e. if the device is disarmed, the device will be armed, and without call answering will be declined it;
- "**END**". The received call will be declined.

The field "**Received message**" has 2 parameters to choice:

- "**Ignore**". Any received SMS will be ignored;
- "**Accept**". Receiving and SMS processing;

Parameter "**Quantity**" specifies quantity of attempts. The device will attempt to call to user. The end of dial-up is answer to call.


Parameter "**Duration of connect**" specifies time of active connection;

- "**The length of message**". The connection will be ended automatically after pronunciation respective message;
- "**Specify by user**". The time of connection ending is specified by user and is not depended of pronounced message length.

Activated a parameter “**Suffice to dial-in for message delivery**”, the device is waiting an user answer, after that it will decline the call. User answer is the fact that message is received. The declining the call is occurring in not the chargeable call duration, which will not lead to a call waste.

“**Source**” specify the operation (dial-up and/or SMS) selecting to an active mode. The operation of inputs using for security is available only when the device is armed.

4.3. Navigation parameters



1. GT-20 Configurator
 2. Monitoring
 3. Connection setting
 4. Navigation setting
 5. Packet structure
 6. Inputs
 7. Outputs
 8. Security
 9. Power supply
 10. Peripheral configuration
 11. Auto informer
 12. Event process
 13. Voice message
 14. Diagnostic file
 15. During the parking

16. Select the writing per event mode, min
 17. Period of packet writing during the parking, sec
 18. Movement parameters
 19. Accelerometer delicacy
 20. Time of selecting to "packing" mode after the stopping, sec
 21. Period of packet writing during the movement, sec
 22. Write the packet in each, m, with the 20 km/h speed
 23. Filtering on the straight place. Deflection, degree

24. The drawing of corners
 25. Min corner, degree
 26. Min speed, km/h
 27. Filtering of coordinates during line change
 28. Coordinate filtering
 29. Max HDOP
 30. Min speed, km/h
 31. Max speed, km/h
 32. Max jump of coordinates per 1 sec, m
 33. Max acceleration per 1 sec, m/sec²


Figure 4.4

This window is for:

- The parameter setting of navigation data packet writing to memory of a device;
- The parameter setting of coordinate filtering;
- The choice of protocol and setting of a structure of transmit data packet.

The group “**During the packing**” has 2 parameters:

- “**Period of the packet writing during the packing**” specifies the time interval, at the end of which it will be operated the next packet writing during the vehicle parking;
- “**Select the writing per event mode**”. If the parameter is active, the device suspends the packet writing to memory. The next data packet will write in case of event, the source of which will be movement sensor, the active mode of analog inputs, absent of external voltage.



<ol style="list-style-type: none"> 1. GT-20 Configurator 2. Monitoring 3. Connection setting 4. Navigation setting 5. Packet structure 6. Inputs 7. Outputs 8. Security 9. Power supply 10. Peripheral configuration 11. Auto informantor 12. Event process 13. Voice message 14. Diagnostic file 15. Protocol 16. Packet structure 17. Device state 	<ol style="list-style-type: none"> 18. Voltage of source and battery 19. Device temperature 20. State of inputs and outputs 21. Inputs voltage 1-2 22. Inputs voltage 3-4 23. Inputs voltage 5-6 24. Inputs voltage 7-8 25. External temperature 1-4 26. External temperature 5-8 27. iButton key code 28. Data of frequency input 29. Fuel level Omnicomm 30. Data 1 of CAN bus 31. Data 2 of CAN bus
---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Figure 4.4.1

Group “**Movement parameters**”.

“**Accelerometer delicacy**” Dimensionless quantity, which specifies the level, in case of exceeding it, the device will switch into a “movement” mode.

The level is setting experimentally. In a case of a false operation during a parking with an operating engine of extreme vibration, the present parameter is necessary to increase.

“**The time of switching into “parking” mode...**” If during the indicated time the movement sensor has passive state, the device is switching into “parking” mode.

“**Period of writing the packet during the movement**” specifies the time interval, with which the data packet will record during the movement with the speed lower than 10 km/h.

“**White the packet in each...**”.If the speed is higher 10 km/h the interval of packet writing is specified of travelled distance, which is in proportion to movement. For example, if the speed is lower 20 km/h the parameter equals 30 m, so if the speed is higher 20 km/h and lower 40 km/h the packet write per each 60 m, if the speed is of 40 km/h to 60 km/h – 90 m.

“**Filtering on straight place**”. If the present parameter is active, the additional filtering of coordinates is conducted on the straight place, decline the traffic. In case of straight movement it is controlled the deviation from the course, and if it is not higher specified value, the coordinates is writing to device memory. If the filtering is switched on, the parameter “**Write packet in each...**” is possible to low for more detail road drawing. The examples of writing track with switching off filtering on the straight place (on the left) and with the switching on filtering (on the right) are on the figure 4.5, 4.6, 4.7.

Group **"The drawing of corners"**.

"Minimum corner" is indicated the corner, in a case of lower which write a packet with coordinates to device memory. The value of this corner must be chosen so that on the one side, small maneuvers of vehicle in a straight place does not lead to the writing of data packet, and on the side, the corner should not be large enough to be able to fix the turn.

"Minimum speed" defines a speed, if the value is higher it, the device is check a corner.

"Filtering of coordinates during line change" If the present parameter is enabled, the additional filtering of corners is used via the algorithm. Fixing the moment of vehicle turn, the coordinate analysis begins. If at the end of the analysis the direction of movement remains the same (the car changed a line of road) or changed slightly (the turning angle didn't exceed 30 degrees), coordinates don't register in memory of the device. In case of switched on filtering, **"Minimum corner"** can accept smaller value for more detail drawing of turn.

Group **"Filtering of coordinates"** If the filtering of coordinates is enabled, the analysis of saved coordinates is made. If coordinates didn't pass the check to any parameter, last coordinates are not saved in the device memory.

"Maximum HDOP" sets the maximum parameter value of horizontal delicacy.

"Minimum speed" is a minimum speed of movement.

"Maximum speed" is a maximum speed of movement.

"Maximum jump of coordinates" defines the maximum distance between two coordinates.

"Maximum acceleration" is an acceleration, coordinates are filtered if the value is higher it.

Group **"Pre-setting"**. This group allows selecting one of three settings.

Group **"Protocol"** allows selecting the data transmission protocol to the server.

Group **"Packet structure"**. Optional data which will be transferred to the server together with a basic data are selected in this group. The basic (invariable) data include: number of the device, package number, date and time, location, speed, direction, altitude, HDOP. The first packet header (sent during connection of the server) contains information about: software version, IMEI, device number.




Figure 4.5




Figure 4.6



Figure 4.7

4.4. Inputs



- 1. GT-20 Configurator
- 2. Monitoring
- 3. Connection setting
- 4. Navigation setting
- 5. Inputs
- 6. Input 1-8
- 7. Outputs
- 8. Security
- 9. Power supply
- 10. Peripheral configuration
- 11. Auto informantor

- 12. Event process
- 13. Voice message
- 14. Diagnostic file
- 15. Input 1
- 16. Type of input
- 17. Active input level
- 18. Disturbing zone
- 19. High level
- 20. Current value
- 21. Low level

- 22. The length of the averaging filter
- 23. Transition to an active state(x100 msec)
- 24. Transition to the passive state(x100 msec)
- 25. Output 1
- 26. Impulse duration
- 27. Pause
- 28. Repeat
- 29. No response

Figure 4.8

In this window setup of parameters is made for each of eight inputs.

In the field "**Type of input**" is defined an operation mode of the selected input:

- "**Not used**". This input isn't used.
- "**Analog (36 V)**". An analog input with the range of 0 to 36 V
- "**Digital**". The function is the same, as the previous one has.
- "**Analog 5 V**". An analog input with the range of 0 to 5 V
- "**Frequency**". This input is used for signal frequency measurement.
- "**Call to a manager**". The transition of the input to an active state leads to a set of the first number in the list. Repeated transition drops a call.
- "**Arming / disarming**." Transition of the input to the active state changes the security mode, i.e. if the device is armed; the mode is change to the disarming, and vice versa.
- "**Ignition control**". Connected to the ignition switch to control the on / off state of the ignition. This feature is useful if you are using an analog fuel level sensor, the indication of which is displayed during the ignition.

In the field "**Active input level**" is selected the active state of an input:

- "**Low or high**". The input is the active if input level is lower than lower level or higher upper level, the intermediate state is passive.
- "**Low**". The active state of an input is in case of the level is lower than lower level. Any other state is passive.
- "**Free**". The input is the active if input level is between the lower and upper levels, any other is inactive.
- "**High**". If input level is higher than upper level, the state of an input is the active, any other is passive.
- "**Low with a hysteresis**". The active status of an input is in case when the level is lower than lower level, passive state is when higher upper level, a status of an input depends on the movement direction in case when an interval between the lower and upper levels. If level is increased of lower level to the upper level, the state is active. If it is on the contrary, the state is inactive.
- "**High with a hysteresis**". It is the same as for the previous one, but it is on the contrary.

The upper and lower levels of operation are selected in the "**Disturbing zone**". Here the current value of selected input voltage is also indicated. The indicator of a current state is token a blue

color if the input signal is in an inactive zone, "green" if it is in the free zone, "red" if it is in the active zone.

“**The length of the averaging filter**” is the parameter, setting a time during which filtering of input signal and can be set of 100 msec to 1000 msec.

In the group "**Transition to an active state(x100 msec)**" it is specified actions for each output in transition of input to an active state.

In group «**Transition to the passive state(x100 msec)**» it is set action for each output in transition of input to the passive state.

The choice of one of four options is available to each output:


- «**No response**». The output doesn't react;
- "**Off**". The output will be transferred to an inactive state;
- "**On**". The output will be transferred to an active state;
- "**Impulse**". The output state will be determined by the settings.

Parameters of the "**impulse**" output:

- "**Impulse duration**" defines the time during which the output will be active. Time is multiples of 100 msec;
- "**Pause**" defines the time between repetitions of the impulse. Time is multiples of 100 msec;
- "**Repeat**". Parameter specifies the number of impulse repetitions. A value=255 will result of infinite repetition of impulse until the following state transition of an output.

«**Frequency threshold**» (it is active, if input type is frequency)field is used to process the events. The exceeding of this threshold is considered that the frequency input is passed to the active state.

4.5. Outputs



1. GT-20 Configurator
 2. Monitoring
 3. Connection setting
 4. Navigation setting
 5. Inputs
 6. Outputs
 7. Security
 8. Power supply
 9. Peripheral configuration
 10. Auto informantor
 11. Event process

12. Voice message
 13. Diagnostic file
 14. Allow to control of outputs via SMS
 15. Allow to control of outputs via DTMF
 16. Active output state
 17. Output 1
 18. Output 2
 19. Output 3
 20. Output 4

21. The logic of output operation controlling via DTMF
 22. Output 1
 23. Impulse duration
 24. Pause
 25. Repeat
 26. No response
 27. Output 1 is a speed sensor simulation
 28. Impulses/km

Figure 4.9

This window is used for parameter setup of each output.

"Allow to control of outputs via SMS". Switching on of this parameter allows to control of outputs through SMS commands.

"Allow to control of outputs via DTMF". Switching on of this parameter allows to control of outputs via DTMF commands.

"Active output state" group defines the state (open or closed), which the output have when it is activated.

In the group **"The logic of output operation controlling via DTMF"** it is specified actions for each output in case of its activation. Parameter setup is described in section 4.4 "inputs".

"Output 1 is a speed sensor simulation". Switching on of this function allows to receive impulse sequence at output with duration which is proportional vehicle motion speed (on the basis of the navigation solution). Using instead of the standard speed sensor. When using this function attentively program the operation of outputs, i.e. in this case it is forbidden to use this output in an event handler.

"Impulses/km". The parameter, setting number of pulses which shall appear at an output when passing 1 km of a way. Calculated of the following formula:

$$\text{Impulses / km} = \text{imp / rev (speed sensor)} * \text{rev / km (transmitting number)}$$


Suppose the speed sensor produces 6 pulses in own revolution at the output, we get 6 imp / rev.

Transmitting number is the number of revolutions that makes the speed sensor when passing 1 km of the way, is determined of the vehicle construction, assume 1000 rev/ km.

By the data obtained: 6000 impulses / km.

If connecting to the tachograph it is used frequency divider (Level adapter), and knowing the division ratio, you can immediately correct the value.

4.6. Security



1. GT-20 Configurator
 2. Monitoring
 3. Connection setting
 4. Navigation setting
 5. Inputs
 6. Outputs
 7. Security
 8. Power supply
 9. Peripheral configuration
 10. Auto informatory
 11. Event process
 12. Voice message

13. Diagnostic file
 14. Activate a security mode
 15. Protected inputs
 16. Arm / disarm
 17. i-Button code
 18. Time of disarmed, sec
 19. Time of armed, sec
 20. Restore inquiry time, min
 21. In case of alarm to make pictures of the camcorder

22. Save to the carrier
 23. Send to the server
 24. Armed
 25. Disarmed
 26. Alarm
 27. Time is multiple of 100 msec
 28. Output 1
 29. Impulse duration
 30. Pause
 31. Repeat
 32. No response

Figure 4.10

Parameter of «**Activate a security mode**» allows or forbids function of device security.

In group «**Protected inputs**» are specified those inputs which must be controlled. The motion sensor is monitored whenever the device is protected and the prohibition of its control is not possible.

Group of "**Arm / disarm.**"

For the control security it is possible to record up to five keys Touch Memory. In the field of the table is entered the code, specified on a key in hexadecimal form, for example «00000B57C5D0». The key code is entered automatically by touching the key to the contactor.

"**Time of disarmed, sec**" sets the time for the device disarming since the moment of fixing the violation of any monitored inputs. Time does not apply to the motion sensor activating. In other words, if during this time the device will not be disarmed, the penetration is fixed and alarm is processed.


"**Time of armed, sec**" sets the time during which the device will not respond to changes of inputs since the start arm (touching of a key).

"**Restore inquiry time, min**" sets the time after which since the moment of alarm fixing if the last one wasn't disarmed, the device conducts re-arming.

"**In case of alarm to make pictures of the camcorder**". If the external JPEG camcorder is connected, in case of alarm, the device will receive continuously pictures from the camcorder, with an interval in a second, and to save to internal SD card ("**save to the carrier**") or to send directly to the server ("**send to the server**"). The interval of receiving depends on the selected image resolution and bit rate. Recording is stopped in case of alarm removal.

Tabs "**Armed**", "**Disarmed**" and "**Alarm**" set the action for each output. Arming is executed via time of arming or immediately after receiving the command via SMS or from the server.

4.7. Power



1. GT-20 Configurator
2. Monitoring
3. Connection setting
4. Navigation setting
5. Inputs
6. Outputs
7. Security
8. Power supply
9. Peripheral configuration
10. Auto informatory
11. Event process


12. Voice message
13. Diagnostic file
14. External power supply
15. Output control in case of voltage reduction lower ...
16. Response time, sec
17. Output 1
18. Impulse duration
19. Pause
20. Repeat
21. No response

Figure 4.11

The device provides output control while reducing the external voltage below the threshold.

If the external voltage is below a predetermined threshold "**Output control ...**" and during the time "**Response time, sec**" is not recovered, turn on output control with the specified parameters. Parameter setup is described in section 4.4 Inputs.

4.8 Periphery setup



1. GT-20 Configurator
2. Monitoring
3. Connection setting
4. Navigation setting
5. Inputs
6. Outputs
7. Security
8. Power supply
9. Peripheral configuration
10. Auto informatory
11. Event process
12. Voice message

13. Diagnostic file
14. Operation mode
15. Combined
16. Involve the CAN interface
17. Speed
18. Involve RS232/RS485 1
19. Speed
20. Type of the connected device
21. Not defined
22. Involve RS232 2

23. Speed
24. Type of the connected device
25. Not defined
26. Logfile writing to SD-card
27. NMEA transmission via USB
28. Thresholds of external temperature
29. Lower
30. Upper
31. Scanner of CAN bus

Figure 4.12

Group "**Operation mode**" is active if the GLONASS receiver is installed in the device. From the drop down list the operation mode is selected:

- "**Combined**". The current coordinates are determined, using data of GPS and GLONASS satellites;
- "**Only GPS**". Data are used only of GPS satellites;
- "**Only GLONASS**". Used data only of GLONASS satellites.

By default, the receiver solves the navigation problem in 3D mode. In case of insufficient number of satellites the receiver can pass to a 2D mode if it is authorized "**Allow 2D**".

"Involve the CAN interface". Switching on of this parameter allows operation of the built-in CAN interface for more information from the vehicle CAN bus. The CAN interface is used only for data receiving. From the "**Speed**" list is selected data rate of CAN-interface, and can be set of 100 Kbit / sec to 1Mbit/sec.

"Involve RS232/RS485 1". Switching on of this parameter allows operation of the first digital interface. This interface can work in the RS232 (CMOS) or RS485 mode. Switching is done directly on the devices.

"Involve RS232 2." Enabling this parameter allows the operation of the second digital interface. This interface can operate in RS232 (CMOS) or RS232 (UART) mode. Switching is done directly on the device.

Field "**Speed**" set the data rate for the first and second interfaces. The speed can be selected from the list or be entered manually.

The field "**Type of the connected device**" defines the device connected to the first or second interface.

- "**Not defined**". The additional device isn't connected to the interface.
- "**Fuel sensor Omnicomm (FS-E)**" Digital fuel sensor is working to a protocol compatible with the protocol Omnicomm. To receive and process the data from the sensor, you must specify the address of the "**Network address of 1 sensor**" (Figure 4.13). The process of the sensor calibration and address assignment are specified in a manual the appropriate sensor.




Figure 4.13

The conversion data function from the sensor can be switching on in the device directly in liters of calibration tables stored in device memory. If the parameter "**Value of a complete tank 1**" is equal to zero, data from the sensor are deduced without conversion, i.e. directly a digital code from the sensor. Value of a complete tank is entered in liter capacity.

The "**Value sum of the two sensors**" parameter is active in the case, if the two sensors are connected to either RS232 or RS485, and the value of a full tank for each sensor is not equal to zero. Enabling this parameter leads to the indications of the sensors are summed, and the amount to be deduced as the indication of the first sensor.

To click the button "**Edit the table**" leads to opening of an additional window for editing of calibration table data (a figure 4.14).

Filling process of the calibration table is the following:

1. Read a device configuration ("**Read**");
2. Value of a complete tank put equal to zero in order to display data directly from the sensor;
3. Write the configuration to the device ("**Write**");
4. Open the calibration table and transfer to the "**Monitoring**" tab;
5. Waste a tank, and, having waited for some time (10 seconds) during sensor indications aren't stabilized yet, in line "**Empty tank**" of the calibration table, enter the indication "**Level 1**" on the tab "**Monitoring**". Indications of the sensor can be also entered another way: click the right mouse button on the selected cell and from the menu select point "**Insert the current value**";

6. Further, assumed that value of a complete tank is equal to 100 liters and divided into 20 equal parts, receive a step of 5 liters **"filling"**;
7. Fill the tank with 5 liters of measured liquid. Having waited for some time (10 seconds), enter the sensor indication into the next line of the calibration table ("1/20");
8. Repeat step 7 until the tank won't be filled completely. For the correct operation of the conversion algorithm, it is necessary to fill the calibration table completely;
9. After the completion of table editing, click to button **"Save"** for saving of the made changes;
10. In the **"Value full tank 1"** field enter the value of a full tank, in this example, 100 liters;
11. Save the table in the device memory by pressing the **"Record"** button.




Figure 4.14

- **"JPEG camcorder C328"**. Device is connected with the external JPEG camcorder C328 or other compatible protocol camcorder. In the field **"Resolution"** is selected image resolution with which it will save to the external carrier (a figure 4.15).

The button **"View"** allows receiving images from a camcorder with a resolution specified in the **"Resolution"** to set its position.

- **"Sensor (s) of fuel RS485"**. Digital or fuel sensors with the RS485 interface are compatible with the protocol Omnicomm (Figure 4.16). The setup process is described above in the description of **"Fuel sensor Omnicomm"**.




Figure 4.15




Figure 4.16

<ol style="list-style-type: none"> 1. Involve RS232/RS485 1 2. Speed 3. Type of the connected device 4. Fuel sensor RS485 5. Network address of 1 sensor 6. Value of a complete tank 1 7. Network address of 1 sensor 8. Value of a complete tank 1 9. Value sum of the two sensors 10. Edit the table 	<ol style="list-style-type: none"> 11. Involve RS232/RS485 1 12. Speed 13. Type of the connected device 14. JPEG camcorder C328 15. Resolution 16. Size, byte 17. View
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

- **"Vehicle K-Line."** The device is connected to the vehicle K-Line via the appropriate transformer.

- **"Radio module of 433 MHz"**. The radio-frequency module is connected to the device.


"The record of Logfile to a SD card". Switching on of this parameter allows record of the diagnostic file to the external carrier. If the device is connected to a configurator, record of the diagnostic file is suspended. Start diagnostic recording leads to a slight reduction in device operation, therefore to use this function it is desirable only if it is necessary to carry out device diagnostics in movement when connection of a configurator is impossible.

"Scanner of CAN bus." Enabling this parameter allows viewing incoming messages based on CAN-bus vehicle.

Group "**Thresholds of external temperature**" is used when processing events from external temperature sensors. If the threshold "**Lower**" is less than the threshold of "**Upper**", it is considered that the source is switched to the active state. This state will be active as long as the temperature will not become below the lower threshold, thus the state will change a mode to a passive. Passive state will be active until the temperature transition through the upper level. If the "lower" threshold is higher the "**Upper**" threshold and algorithm is the same, but while the temperature transition of the upper level, it is considered that the source was passed to the passive state.

"**NMEA translation via USB**". If the parameter is enabled, NMEA messages coming from a satellite receiver will be translated via the USB port.

4.9 Auto informer



1. GT-20 Configurator
2. Monitoring
3. Connection setting
4. Navigation setting
5. Inputs
6. Outputs
7. Security
8. Power supply
9. Peripheral configuration
10. Auto informatory
11. Event process
12. Voice message
13. Diagnostic file

14. Enable Autoinformer
15. Route file
16. List of geozone coordinates
17. Latitude
18. Longitude
19. Name of the reproduced file
20. Open
21. Read
22. Common quantity of geozone
23. Save as a file
24. Write

Figure 4.17

The device has a function autoinformer. To use it, you must enable the parameter "**Enable Autoinformer**". Autoinformer operation can lead to insignificant decline of device productivity. Before using the autoinformer, you need to prepare audio files and edit the route files.

Remove the SD-card from the device and connect it via a card reader to your computer.


Create "**Autoinfo**" folder in the root of SD-card and place there the audio files with the following parameters: wav, PCM, 12 kHz, mono, 8 bit. File name length with filename extension must not exceed 29 characters. For example: Naberezhnaya.wav.

Start the Configurator to create or edit a file of a route "**Marshrut.fai**" and go to the tab "Autoinformer".

Adding geozones coordinates (Figure 4.17) can be either manually or using the context menu (Figure 4.18). Last one is a useful when recording a route following to it. To call a context menu click right mouse button to the selected cell.

The following parameters are entered for each geozone:

- Latitude;
- Longitude;
- Internal radius of an actuating zone (Rin);
- External radius of an actuating zone (Rext);
- A name of the reproduced file.



1. List of geozone coordinates
2. Open
3. Read
4. Latitude
5. Longitude
6. Name of the reproduced file
7. Insert the current coordinates
8. Select File
9. Add a line
10. Delete a line
11. Delete everything
12. Common quantity of geozone
13. Save as a file
14. Write

Figure 4.18

The context menu items:

- **"Insert the current coordinates"** Insert the current location in the selected cell;
- **"Select File."** Allows specifying the file to be displayed at the entrance to the current geozone. Files should be indicated only those that are in the «Autoinfo» folder;
- **"Add a line"** Add another line of geozone parameter. The maximum number of geozone is limited to 100;
- **"Delete a line"**. Deletes the line for the selected cell
- **"Delete everything"** Remove all parameters of geozones.


After entering the geozones parameters, save the route file **"Save as a file"** to the «**Autoinfo**» folder. Saved it in another folder will cause of the autoinformer function will not work.

If the file of a route is created and it is necessary to edit it, use the **"Open"** button.

Further inset a SD card into the device and reboot it.

To edit the file of a route is possible without removing a SD-card from the device. For this purpose set connection with the device, transfer to the tab **"Autoinformer"** and click the **"Read"** button. The read file will be displayed in the appropriate table. After editing of route parameters for saving the file click the **"Write"** button.

4.10 Event Processing



1. GT-20 Configurator	15. Event 1	30. Input 1-8	44. Operating time of timers
2. Monitoring	16. Source	31. Action	45. Timer 1
3. Connection setting	17. State	32. Output 1 is on	46. Timer 2
4. Navigation setting	18. No source	33. Output 1 is off	47. Operating time of timers, 100 msec
5. Inputs	19. Transferred to active	34. Output 2 is on	48. Timer 3
6. Outputs	20. Conditions	35. Output 2 is off	49. Timer 4
7. Security	21. Logic	36. Output 3 is on	
8. Power supply	22. AND	37. Output 3 is off	
9. Peripheral configuration	23. OR	38. Output 4 is on	
10. Auto informatory	24. Accelerometer	39. Output 4 is off	
11. Event process	25. Input 1-8	40. Replay the message	
12. Voice message	26. Condition state	41. Send SMS to number 1	
13. Diagnostic file	27. Active	42. Dial a number	
14. Event Processing	28. Passive	43. Report to server	
	29. Accelerometer		

Figure 4.19

To switch on "**Event Processing**" allows the user of the available resources to organize their own algorithm (s) of the device.

To the user it is available to program up to 20 events.

The event source is selected in the field "**Source**" from the available list.

In the "**State**" field the state is set to which the source is transferred or have: "**Transferred to passive**," "**Transferred to active**", "**Passive**," "**Active**".

"**Logic**" defines a mode of condition check.

"**And**" - action will be executed if all specified conditions are in the selected state.

"**OR**" - action will be executed, if at least one of the specified conditions is in the selected state.

The conditions are selected in the field "**Conditions**" in case of which the event source state is checked. The condition can be not specified, and the operations are executed for a selected source state.

Condition state (active / passive) is set in the "**Condition state**" field, which is checked when processing the event, if the condition is selected.

In the field "**Action**" actions is specified which are necessary for executing. If "**Replay the message**" is selected as action, it is necessary that there was an "event_X.wav" file on a SD card in the "**Voice**" folder, where X is an event number of 1 to 20. Parameters of the sound file: wav, PCM, 12 kHz, mono, 8 bits.

Algorithm of event processing is the following: if "**Source**" passed to "**State**" in case of execution of selected "**Conditions**", it is carried out selected "**Actions**".

Action "**Send SMS**" and "**Dial a number**" tied to the events. For example, the events of 1 to 4 is attached the first number in the list, the events of 5 to 8 is attached the second number and etc.

«**Operating time of timers**». This field represents the time interval of the timer operation, if the last are used in the event processing. The operation time of timer #1 and #2 is multiple of 1 sec, and timers #3 and #4 is 100 msec.

When programming it is necessary to remember, that value of a source and a condition weren't identical, otherwise the event cannot occur.

Consider the following example. The external indicator in the form of LED is connected the output#2 via a current limiting resistor to the supply voltage. It is necessary that in case of object movement indicator briefly flashed one time per second.

To implement this algorithm requires two events, "**Event 1**" is to activate the indicator and "**Event 2**" is to turn off the indicator.


"Event 1" program to the following way:

- As the "Source" select "Timer 1, sec";
- "State": "Switch to the active";
- "Logic" - any, as a condition is one: "The movement of the object";
- "The condition state" - "The movement of the object" ticks off, i.e. in the active status;
- As executed action select «Output 2 is on».

"Event 2" will have other parameters:

- "Source": "Output 2";
- "State": "Active";
- "Logic": any;
- "Condition": It is possible not specified, or if the output is used in other events, the "movement of the object";
- "The condition state" - "The movement of an object" - "Action": "Output 2 is off."

4.11. Voice message



<ol style="list-style-type: none"> 1. GT-20 Configurator 2. Monitoring 3. Connection setting 4. Navigation setting 5. Inputs 6. Outputs 7. Security 8. Power supply 9. Peripheral configuration 10. Auto informatory 	<ol style="list-style-type: none"> 11. Event process 12. Voice message 13. Diagnostic file 14. Welcome note 15. Enter a password 16. Incorrect password 17. Configuration menu 18. Output control is forbidden 	<ol style="list-style-type: none"> 19. External voltage is lower... 20. Armed 21. Disarmed 22. Movement sensor is activated 23. Input 1-8 is activated 24. Output 1-4 is activated 25. Output 1-3 is deactivated
----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Figure 4.20

This page allows working with the files which are storing on a SD card, without pulling out it from the device.

In the group "**Voice messages**" it is bonded of audio file to a appropriate voice message. Select a cell of voice message that you wish to bind a file, and then clicking the right mouse button to a dialog box in which specify the audio file and click "**Open**".

In the appropriate cell there will be a way to the selected file.

The button "**Save to the carrier**" is used for copying of the selected audio files to device SD card.

The button "**Clear**" is to clear all field of table.

The "**The list of available**" is displayed a list of files which is present on the carrier.

4.12. Diagnostics file




Figure 4.21

Group «**Diagnostics file**» allows reading the saved file of diagnostics. For this purpose in the field "**Date**" select day for which it is necessary to receive the file of diagnostics and click the "**Read**" button.